

2 Talk setup for Akuvox Devices

Akuvox Device

- Log into the device
- Go to Account settings and change the Account at the top to view Account 2

SIP Account

Status	UnRegistered
Account	Account 2 ▼
Account Enabled	☐
Display Label	
Display Name	
Register Name	
User Name	
Password	

Preferred SIP Server

Server IP	
Port	5060 (1024~65535)
Registration Period	1800 (30~65535s)

- Tick “Account Enabled”
- Now fill out the following fields with information from 2Talk:

Field	What you enter from 2Talk
Display Label	Extension Number
Display Name	Extension Number
Register Name	Extension Number
Username	Extension Number
Password	Whatever password 2Talk sent you
Server IP	The server IP 2Talk sent to you