# **HTTP Commands**

### **HTTP URL format**

### Open door via HTTP command

https://username:password@deviceIP/fcgi/OpenDoor?action=OpenDoor&DoorNum=1

#### Example:

https://admin:Admin1234@10.1.10.109/fcgi/OpenDoor?action=OpenDoor&DoorNum=1

Change the number at the end to open certain relays.

- 1 = Relay A
- 2 = Relay B
- 3 = Relay C

## HTTP Open Relay: Gate to Monitor

Gate will be an E18C

Monitor will be an \$567

**Goal:** Have a particular relay in the Gate Intercom when triggered, sends an HTTP command to trigger the relay in the Monitor.

- Log into the S67
- Navigate to Device > Relay
- Enable Open via HTTP and enter a Username and Password
- Note the IP address of the S567.
- Create a HTTP URL using the following Template:

https://username:password@deviceIP/fcgi/OpenDoor?action=OpenDoor&DoorNum=1

Remember to specify what Relay to activate

- 1 = Relay A
- 2 = Relay B
- Log into the E18C
- ❖ Navigate to Access Control > Relay
- Enable Open Via HTTP

- ❖ Navigate to Settings > Action URL
- Paste the HTTP URL in the relay you want to fire Relay B triggered or Relay A triggered
- ❖ Submit